

FRIDGE/FREEZER THERMOMETER

Operating Instructions

Product code:

TMM105 AND TMM105C



INSTRUMENT OPERATION - The instrument will turn on once the battery is installed. **Please note:** This product cannot be placed within the fridge or freezer. Place the probe within the fridge or freezer using the sucker or fixing provided. The instrument reading may take a few seconds to stabilise. The probe will measure the temperature of the fridge or freezer and 'FRIDGE' will be shown in the display. To change the display to measure the room temperature press the FRIDGE/ROOM button and ROOM will be displayed.

TEMPERATURE ALARM SETTING FRIDGE ONLY - To set the audible alarm, press and hold the ALARM SET button, the high alarm temperature will flash in the display. To set the high alarm, press the °C/°F button at the rear of the unit to adjust the temperature. To set the low alarm press the ALARM SET button again, and press the °C/°F button to adjust the temperature. Press the ALARM SET button to confirm. To turn on the alarm press the ALARM SET button and AL will display. The audible alarm will only sound when the temperature had been exceeded for 5 seconds, and again every 55 seconds thereafter.

Please note: this alarm only works on the fridge/freezer probe.

MAX/MIN - Press the MAX/MIN button to display the maximum reading (MAX symbol displayed). Press the MAX/MIN button again to display the minimum reading (MIN symbol displayed). Press MAX/MIN button again to return to normal readings. Hold MAX/MIN for three seconds to reset minimum and maximum temperature memory.

°C/°F FUNCTION - Press the °C/°F button on the back of the instrument to switch between Centigrade and Fahrenheit.

BATTERY REPLACEMENT - Replace the battery immediately the reading becomes erratic or the display clarity fades, using a AAA battery or 1.5V equivalent. The battery is located under the battery cover at the rear of the instrument.

EMC/RFI - Instrument performance may be affected if operated within a high frequency radio field, such as near a mobile phone, or if subjected to an electrostatic shock.

GUARANTEE - This instrument carries a one-year guarantee against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of Denward, be either repaired or replaced without charge. This guarantee does not apply to sensors/probes, where a six-month period is offered. The product guarantee does not cover damage caused by fair wear and tear, abnormal storage conditions, incorrect use, accidental misuse, abuse, neglect, misapplication or modification. Full details of liability are available within Denward's Terms & Conditions of Sale at www.denward.com. In line with our policy of continuous development, we reserve the right to amend our product specification without prior notice.